



**EU
Code List**

TV Code List	
ACCENT	0081,1181,1361,1701,8271
ACCUAPHASE	1361
ACER	1321
ACOUSTIC SOLUTIONS	2121
ACTION	0021,0081,0911,1191,1801
ACURA	0081,1181
ADCOM	1291
ADLER	4101,8191
ADMIRAL	0021,0071,0081,0371,1021,1721,1811,2191
ADVENT	2651
ADVENTURA	6951
ADYSON	0021,0951,1111,1851,1861,2221
AEA	0141,1181,1361
AEG	0141,1661,1731
AGASHI	0811,1851,1861
AGATH	1761,6961
AGB	0951
AGEF	1021
AIKO	0151,1331,1361,1701,1811,1861,8271
AIM	1181,1361,1731,1771,1821,8271
AIRIS	4381,6971,7241,7251,7721
AIWA	3391
AKAI	0041,0321,0441,0461,0551,0951,1061,1081,1091,1111,1181,1331,1651,1701,1731,1761,1771,1811,1861,1871,2071,3211,4371,6741,6931,8271
AKASHI	1701
AKIBA	1081,1181,1361,8271
AKITO	1181,1361,8271
AKURA	0021,0041,0081,1081,1181,1361,1701,1811,4381,8271
ALARON	1851
ALBA	0041,0071,0411,0661,0951,1061,1081,1091,1181,1701,1851,1871,2091,2541,8271
ALBIRAL	0671
ALDEN	7261
ALFA	0021
ALIEN	1181,8271
ALLORGAN	0811,0951,1151,1861
ALLSTAR	0021,1181,1361,8271
ALLVIEW	7141
ALPHA	4101,6541,7271
ALPHA DIGITAL	7731,7741
ALPHATRONICS	7281
ALTEK	6981
ALTUS	4171
AMBASSADOR	0141,2261
AMERICAN HIGH	1801
AMITECH	6991
AMPLIVISION	0411,0951,1861
AMSTRAD	0081,0291,0461,0741,1101,1181,1361,1701,1811,8271
ANAM NATIONAL	1181,1361,1701,1711,8271
ANDERSSON	1661
ANGA	0141,2261
ANGLO	0081,1701,1811
ANITECH	0351,1081,1111,1201,1361,1701,1811,2221,8271
ANSONIC	0071,0081,0411,1181,1201,1231,1321,1361,1701,8271
ANTARION	6401
AOC	0021,1111,2001,7921
AR SYSTEM	0711,1181,1361,2241
ARC EN CIEL	0841,0851,0911,1071,1211,1241,1271
ARCAM	0951,1241,1851,1861
ARCELIK	4171
ARCON	1661
ARCTIC	4171
ARDEM	0041,1181,1361,8271
ARENA	1871,8271
ARIELLI	4101,4111
ARISTONA	0021,1141,1181,1321,1361,8271
ARSTIL	4171
ART TECH	0021
ARTHUR-MARTIN	0071,0241
ASA	0071,0341,0501,0511,1021,1441,2181,2191
ASBERG	0021,0351,0591,1181,1201,1361,8271

TV Code List	
ASORA	0081,1701
ASTON	2011
ASTRA	0081,1181,1361,8271
ASUKA	0951,1081,1811,1851,1861
ATASHII	2601
ATD	1821
ATEC	7001
ATLANTIC	0021,0811,1181,1361,1511,1851,8271
ATORI	0081,1701
ATORO	0081
AUCHAN	0071,0241
AUDIOSONIC	0041,0411,0951,1081,1211,1231,1361,1591,1651,1701,1811,1861,8271
AUDIOTON	0081,0411,0951,1811,1861
AUDIOVOX	0021
AUDIOWORLD	1821
AUMARK	1801
AUTOVOX	0811,0951,0991,1021,1151,1181,1351,1861,2191,8271
AVOL	1791
AVTEX	6771
AWA	1131,1171,1701,1731,1811,1861,2441
AXEN	7291
AXION	7011
AXXENT	1701
AXXON	0041
BAIRD	0821,1211,1731,1771,1861
BANG & OLUFSEN	0801,1011,1021,2191,2351
BARCO	0071
BASIC LINE	0071,1081,1181,1231,1701,1861,8271
BASTIDE	0951,1861
BAUER	0461,1701,1811,1821
BAUR	0141,0151,0451,0461,0501,1181,1281,1301,1331,1351,1361,1701,8271
BAZIN	1861
BBK	1541,1551,1561,1571,1991,2421
BEAUMARK	1761
BEC	0021,0951
BECRESE	0021,0141,0501,0911,1061,1111
BEKO	0041,0411,0491,0891,1591,1651,1731,4171,8271
BELL & HOWELL	0021
BELSON	1831
BELSTAR	1181,8271
BENCHMARK-BEAUMARK	0021
BENQ	0081,1111,1801,2001
BENQ	2001
BEXA	0021,0591,1181,1361,8271
BEST	0411
BEST BUY	7301,7311,7321
BESTAR	0021,0071,0411,1181,1231,1361,8271
BESTAR-DAEWOO	1231
BEXA	2051
BIGSTON	0081
BINATONE	1861
BLACK DIAMOND	1181,1361,1661,8271
BLACK PANTHER	1201
BLACKSTRIPE	0501,1061,1801
BLAUBERG	2601
BLAUPUNKT	0251,0431,0441,0451,0461,0481,1081,1091,1331,1751,2091
BLOMBERG	4171
BLOOM	1181,8271
BLU-SENS	1761
BLUE	0001
BLUE SKY	0021,0041,1081,1181,1361,1591,1831,4381,8271
BOGO	4111
BOLVA	2621
BONDSTEC	0991,1151,1701,1861
BPL	1181,1361,8271
BRANDT	0751,0761,0771,0841,0851,0911,1071,1221,1241,1251,1271,1291,2101,7901
BRAVO	1871
BRENDSTAR	0081
BRIGMTON	6431,7331
Brimax	7171
BRINKMANN	0021,0591,1181,1361,8271
BRIONVEGA	0021,0351,0591,1021,1181,1361,1661,8271

TV Code List	
BRIORRYEGA	0001,2191
BRITANNIA	1851,1861
BROCKWOOD	0141,1061,1111,2261
BROKSONIC	0141,1061,1111,1061,1081,1091,1161,1181
BROTHER	1811
BRUNS	1021,2191
BSR	0071,0151,1151
BTC	1081
BUSH	0041,0151,0661,0951,1061,1081,1091,1161,1181,1231,1361,1651,1701,1771,1811,1821,1861,1871,2001,2231,2761,4371,8271
CAMERON	1451,1461,1481
CAMPLE	0141,1061,1111,2261
CANCA	8031
CANDLE	1111
CAPEHART	0021,1061,1111
CAPSONIC	1811
CARAD	1181,1361,8271
CARENA	1181,1361,8271
CARREFOUR	0021,1061,1181,1361,8271
CARVER	0021,1751
CASCADE	1181,1361,1701,8271
CASIO	0071,1181,1351,1361,8271
CATHAY	0021,1181,1361,8271
CCE	1181,1361,1861,8271
CCI	0471
CELLUS	1871
CELCO	2531,2551,3471,4681
CENTURION	0021,1181,1361,2641,8271
CENTURY	0991,1001,1021,1341,2191
CGE	0071,0081,0211,0351,0411,0591,0991,1001,1241
CGM	1081,1081
CHANGHONG	0001,1391,6441,6451,6461,6471,6481,6491,6501,6931,7181,7191
CHIQ	0001,4501,7341
CIE	0081,0461,1231
CIHAN	0021
CIMLINE	0081,1091,1701
CINEX	0021
CIRCUIT CITY	0141,1061,1111,2261
CITIZEN	0021,1111,1801
CITY	0081,1701
CLAIRSTONE	1871
CLARIVOX	0621,0971,0991,1181,1201,1361,8271
CLATRONIC	0041,0071,0351,0411,0951,0991,1001,1081,1201,1361,1701,1731,1811
CLAYTON	1651,1871,4221
CMS	1851
CMS HIGHTEC	1861
CMX	3431,6741
COLORTYME	0021,1801
COLOSSUS	7351
COMPUTRON	0081
CONCORDE	0081,1701
CONDOR	0071,0411,0991,1201,1361,1701,1811,1851,8271
CONIA	2951
CONIC	0021,1061,1111
CONRAC	0651
CONRAD	1181,1361,8271
CONTEC	1061,1081,1171,1361,1701,1811,1851,8271
CONTEX	4111
CONTINENTAL EDISON	0111,0751,0761,0841,0851,0911,1071,1241,1271
COOCAO	3431
CORONADO	1111
COSMEL	0081,1181,1361,1701,8271
CRAIG	0021,2481
CROSLLEY	0221,0351,0991,1001,1021,1061,2191
CROSSWOOD	1181,8271
CROWN	0041,0071,0351,0411,1111,1181,1591,1701,1731,1741,1771,8271
CRYSTAL	0021
CSC ELECTRONICS	1851
CTC	0991
CTC CLATRONIC	0591
CURTIS MATHES	0021,1061,1111,1721,1801,6261
CYBERTRON	0951
DAENYX	6931
DAEWOO	0041,0091,0721,0951

TV Code List	
DAICHI	0081
DAINICHI	1081,1851
DANSAI	1061,1111,1181,1361,1701,1771,1811,1851,1861,8271
DANTAX	0041,0411,1591,1731
DATSURA	1771
DAWA	0021,1181,1361,1701,8271
DAYTEK	1811,1821
DAYTRON	0081,0501,1111,1181,1231,1361,1701,8271
DE	1181,8271
DE GRAAF	0071,0321,1771
DEC	4371
DECCA	0021,0601,0651,0951,1041,1171,1181,1361,1861,8271
DEITRON	1181,1231,1361
DELTON	1181,8271
DENKO	1811
DENVER	0031,0081,1181,1361,1731,2881,4381,7621,7631,7751,8271
DESMET	0021,0081,1021,1181,1361,1701,8271
DGM	2101
DIAMANT	1181,1361,8271
DIAMOND	0081,1701,1811,1821,1851
DIGIHOME	1181,1871,8271
DIGILINE	1181,1361,8271
DIGIGLO	1871,8271,8271
DIGIMATE	7021
DIGIQUEST	1871,4111
DIGITOR	0151,1181,1361,1811,1361,8271
DIK	1181,1361,8271
DIKOM	7031
DION	8591
DISNEY	7041
DIXI	0021,0081,1021,1181,1361,1701,1861,8271
DL	0031,4371
DMTECH	1181,1871,8271,8421
DORIC	0311,1351
DSC	1991
DSE	1391,1401,1411,1421
DUAL	0391,0821,0951,1081,1181,1241,1351,1511,1701,1861,1871,2891,8271
DUNAI	2191
DURABRAND	1181,8271
DUX	1181,1321,1361,8271
DVICO	2041
D-VISION	1181,1361,8271
DYNAMIC	0081
DYNATECH	0141,0951,1061,1111,2261
DYNATRON	1181,1321,1361,8271
DYON	2601
E:MAX	1731,2101
EATON	1801
ECCO	1821
ECG	1991,2101,7361,7371,7761
ECR	1061
EDISON	1211,1871
EDUK	1871
ELBE	0151,0411,0441,0971,1311,1331,1341,1361,1861,1871,8271
ELBIT	0021
ELCIT	0071,0991,1021,1201,2191
ELECS	0021
ELECTRATUNE	1111
ELECTRIQ	1871,3211
ELECTRO	0141
ELECTRO TECH	0081
ELECTROPHONE	2261
ELECTRONICS	0991,1081
ELECTRONIKA	0021
ELEKTA	0081,1181,1361,1701,1811,8271
ELEKTRA	4111
ELEKTRABREGENZ	4171
ELEMENT	2621,3591,6621
ELFUNK	1221
ELG	1181,1361,8271
ELIN	0321,0501,1361,1441,1701,1851,8271

TV Code List	
ELIT	2601
ELITE	0021,1061,1081,1111,1181,1361,1801,8271
ELKOS	1871,7381
ELMAN	0071,0671,0871,0891,1201
ELTA	0071,0081,1701,1811,1851
EMERSON	0041,0141,0151,0411,1021,1061,1111,1361,8271
E-MOTION	2091,4381
ENERGY SYSTEM	1371,1381
ENIE	6931
EON	1061,1801
EPC	0651
ERISSE	3441,4181
ERRS	0021,1141,1181,1321,1361,8271
ESC	1181,1361,1861,8271
ESTAR	4111
ESTE	0071
ETRON	0071,0081,0151,1181,1361,1691,1701,8271
EUROFEEL	1811,1861
EUROLINE	1871
EUROMAN	0021,0411,0951,1181,1361,1811,1851,1861,8271
EUROPA	1181,1361,8271
EUROPHON	0071,0671,0961,0991,1201,1361,1861,8271
EUROSKY	1181,8271
EXCEL	1181,1361,8271
EXPERT	0071,0241,0581,0811,1511
EXQUISIT	1181,1361,8271
EYE TV	1941
F&U	2101,3441,4111
FAIRTEC	1801,1831
FAMILY LIFE	1181,1361,8271
FAVORIT	1871
FENNER	0081,1231,1701
FERGUSON	0321,0611,0771,0821,0971,1251,1291,1361,1871,1951,2091,8271
FIDELIS	0081
FIDELITY	0071,0151,0261,1181,1361,1811,1851,8271
FILSAI	0081,1861
FINLANDIA	0071,0151,0321,0751,0771,0821,1771
FINLUX	0041,0511,0571,0951,1201,1441,1591,1861,1871,6581,7051,8271
FIRSTLINE	0041,0151,0951,0991,1151,1181,1201,1231,1341,1651,1701,1771,1831,1861,8271
FISHER	0061,0151,0411,0951,1021,1061,1441,1771,1861,2191
FLAVEL	4171
FLINT	0021,1181,1361,1811,8271
FNR	1201
FORNENTI	0021,0071,0251,0951,1021,1181,1361,1851,2191,8271
FORTRESS	1021,1051,1061,1111,1721,2191
FOX	4101,4111,4121,4231,4241,4251,4261,4271,8201
FRABA	0411,1181,1361,8271
FRIAC	0411,1181,1201,1361,2261
HARWOOD	1181,1361,1701,8271
HAPPAUGE	1181,1361,8271
HCM	0081,0951,1081,1181,1361,1701,1811,1861,8271
HEATHKIT	0021,0141
HEDZON	1181,1361,8271
HEMA	0951,1701,1861,1511,1701,1861,8271
HEMMERMANN	0151,1351
HIFVOX	0841,0851,0911,1071,1211,1241,1271
HIGASHI	1851
HIGH	1801
HIGHLINE	1181,1361,1811,8271
HILINE	0081

TV Code List	TV Code List	TV Code List	TV Code List	TV Code List	TV Code List	SAT / CABLE Code List	SAT / CABLE Code List	SAT / CABLE Code List	SAT / CABLE Code List	SAT / CABLE Code List	SAT / CABLE Code List	Soundbar Code List
PIONEER 0151,0411,0911 1211,1361,1841,1931,3201 3561	ROKU TV 3381 ROSITA 0081 ROSNER 0951 ROWA 0031,0081,1701,1811 1821,1851,1861	SIGNATURE 0141 SILVA 0081,0151,1181,1361 1851 SILVA SCHNEIDER 2951 SILVER 0071,0151,1061,1081 1181,1361,1591 SILVERCREST 1181,1871,8271 SIMPLY 2601 SINGER 0281,0581,0671,0991 1001,1021,1201,1221,1361 1701,2191 SINODYNE 0021 SINOTEC 1731,1821 SINUUDYNE 0151,1021,1201 1281,1301,1731 SKY 1181,1361,1761 SKY GLASS 8331 SKYMASTER 7671,7681,7691 SKYTECH 1871,7531 SKYWORTH 1401,3431 SMARAGD 0111 SMART 2641,7701,7711 SMART TECH 4111 SNYDER 0021 SOGO 2101,7351 SOKOL 0071,1511 SOLAVOX 0071,0151,0321 1181,1361 SONIKO 1181,1361 SONIQ 2121,2131,2141,2151 2161,8731 SONITRON 0411,1051,1771 1861 SONNECLAIR 1181,1361 SONOKO 0041 0021,0081,0951,1181 1361,1701,1811,1861,4111 SONOLOR 0321,0581,1281 1301,1771 SONTEC 0021,0411,1181,1361 1701 SANY 0381,0391,0411,1041 0651,1061,1171,1361,1481 1701,1751,1861,1871,4011 6811,8271,8431 SASO 0911 SAVE 1181,1361 SBR 0021,1141,1181,1191 1321,2191 SCEPTRE 1361 SCHAUB LORENZ 0041,0321 1231,1731,1831,1871,2101 2831 SCHNEIDER 0041,0051,0081 0151,0391,0821,0971,0991 1081,1151,1181,1321,1511 1861,1871,3211,4111,4351 SCHONTECH 1871 SCOTLAND 0071 SCOTT 0141,1061,1111,1761 1971,2261 SEDEA 2991 SEEVUE 7521 SEG 0041,0351,0951,0991 1061,1111,1181,1201,1701 1811,1861,2321,8271 SEI 0071,1021,1181,1201 1281,1301,1351,1361 SEIKI 2621 SEI-SINUUDYNE 0141,0291 0461,1021,1091,1151,1201 1281,1301,1361,2191 SEIZO 2441,2621 SELECLINE 1871,7351 SELECO 0381,0771,0791,0811 0861,1181,1511,1811,8271 SEMUA 1111 SENCOR 2541,6591 SENCORA 0081,1701 SENTRA 0071,0151,1081,1351 1391,1701 SERINO 1721,1851 SHARP 1061,1871,2001,2091 3241,3421,3861,4461,6561 6811,8741 SHINTOM 0141 SHINTOSHI 1181,1361 SHIVAKI 0021,1181,1231 1361,1761,2251,8271 SHORAI 1151 SHOW 0081,1701,1811,1821 SIAREM 0071,0221,0671,0951 0961,1021,1201,2191 SICATEL 0411,0581 SIEMENS 0151,0251,0441 0451,0461,0471,1051,1111 1181,1361,1361 SIERA 0021,0031,0411,1111 1181,1321,1361 SIGMAX 1801	SYDNEY 0951,1851,1861 SYLVANIA 1051 SYMPHONIC 0141,1061,1111 SYSLINE 1181,1361 SYTONG 1851 TANDBERG 0071,0151,0291 0421,0911,1211 TANDY 0071,0951,0991,1081 1721,1861 TMK 1761,1801 TOBO 0081 TOKAI 0021,0071,1181,1231 1361,1701,1861 TOKYO 1581,1801,1851 TONGTEL 0031 TOP SHOW 1701,1811,1821 TOPLINE 1181,8271 TOSHIBA 0041,1181,1791 1821,1871,2861,4061,4181 6441,6811,6841,8271,7131 TOSHIBA (FIRE TV) 4441 TOSONIC 1111,1801 TOTEVISION 1111 TOWADA 0071,1201,1351,1861 TOYODA 1701,1811 TRAKTON 1701,1811,1861 TRANS CONTINENTS 1181,1361 1861 TRANSONIC 0031,1181,1361 1701,1811,1821 TRANSTEC 1851 TRC 0081,1081 TREVI 0081,4111 TRIAD 0021,1181,1361,1701 TRIDENT 0951,1861 TRILUX 0021 TRISTRAR 1081,1811 TRIUMPH 0461,1181,1361 TRIVISION 0081 TUCSON 1651,1821 TURBO-X 7351 TVTEXT 95 1361 UHER 0021,0151,0161,0411 0811,1181,1231,1361,1511 ULTRAVOX 0221,0951,0991 1001,1021,1201,1231,1361 1851,2191 UMA 0021,0071,0311,0751 0911 UNIC LINE 1181,1351,1361 UNIDEN 0131,1871,2541,3441 3591 UNIMOR 0021 UNITED 0031,0041,1161,1181 1361,1591,1871 UNIVERSAL 0041 UNIVERSUM 0151,0411,0451 0501,0521,0661,0811,0991 1061,1171,1181,1211,1271 1281,1301,1441,1701,1751 1791,1811,1861,1871,2901 8271 UNIVOX 0071,1021,1181,1341 1361 URANYA 0081 UTAX 0071 V7 VIDEOSEVEN 1761 VANGUARD 0081,1871 VD TECH 2101 VECO 0081 VELTECH 8671 VENTURER 2161 VEON 8641,8651 VESTEL 1181,1871,2541,4421 8271 VEXA 0021,0081,1181,1361 1701 VICTOR 1741 VIDEO SYSTEM 0021,1181 1361 VIDEOLOGIC 1851 VIDEOLOGIQUE 0951,1081 1851,1861 VIDEOSAT 0991 VIDEOSATTECHNIC 1231,1851 VIDEOTON 0221,0901,0931 1181,8271 VIDIKRON 1201 VIDION 0081 VIDTECH 1061,1761 VIEWPIA 7091 VIEWSONIC 8211 VINCHI 4111 VIOIOLA 1851 VISION 0081,1181,1361,1811 1861,2601,4171 VISION PLUS 8451 VIVISO 7231 VISTAR 0151 VITYAZ 0071,1521	THORN 0011,0141,0151,0331 0451,0481,0501,0511,0611 0651,0941,0971,1061,1131 1141,1221,1231,1281,1301 1341,1361,1391,1441,1531 THORN-FERGUSON 0021,0151 0611,0941,0971,1131,1221 1341 TMK 1761,1801 TOBO 0081 TOKAI 0021,0071,1181,1231 1361,1701,1861 TOKYO 1581,1801,1851 TONGTEL 0031 TOP SHOW 1701,1811,1821 TOPLINE 1181,8271 TOSHIBA 0041,1181,1791 1821,1871,2861,4061,4181 6441,6811,6841,8271,7131 TOSHIBA (FIRE TV) 4441 TOSONIC 1111,1801 TOTEVISION 1111 TOWADA 0071,1201,1351,1861 TOYODA 1701,1811 TRAKTON 1701,1811,1861 TRANS CONTINENTS 1181,1361 1861 TRANSONIC 0031,1181,1361 1701,1811,1821 TRANSTEC 1851 TRC 0081,1081 TREVI 0081,4111 TRIAD 0021,1181,1361,1701 TRIDENT 0951,1861 TRILUX 0021 TRISTRAR 1081,1811 TRIUMPH 0461,1181,1361 TRIVISION 0081 TUCSON 1651,1821 TURBO-X 7351 TVTEXT 95 1361 UHER 0021,0151,0161,0411 0811,1181,1231,1361,1511 ULTRAVOX 0221,0951,0991 1001,1021,1201,1231,1361 1851,2191 UMA 0021,0071,0311,0751 0911 UNIC LINE 1181,1351,1361 UNIDEN 0131,1871,2541,3441 3591 UNIMOR 0021 UNITED 0031,0041,1161,1181 1361,1591,1871 UNIVERSAL 0041 UNIVERSUM 0151,0411,0451 0501,0521,0661,0811,0991 1061,1171,1181,1211,1271 1281,1301,1441,1701,1751 1791,1811,1861,1871,2901 8271 UNIVOX 0071,1021,1181,1341 1361 URANYA 0081 UTAX 0071 V7 VIDEOSEVEN 1761 VANGUARD 0081,1871 VD TECH 2101 VECO 0081 VELTECH 8671 VENTURER 2161 VEON 8641,8651 VESTEL 1181,1871,2541,4421 8271 VEXA 0021,0081,1181,1361 1701 VICTOR 1741 VIDEO SYSTEM 0021,1181 1361 VIDEOLOGIC 1851 VIDEOLOGIQUE 0951,1081 1851,1861 VIDEOSAT 0991 VIDEOSATTECHNIC 1231,1851 VIDEOTON 0221,0901,0931 1181,8271 VIDIKRON 1201 VIDION 0081 VIDTECH 1061,1761 VIEWPIA 7091 VIEWSONIC 8211 VINCHI 4111 VIOIOLA 1851 VISION 0081,1181,1361,1811 1861,2601,4171 VISION PLUS 8451 VIVISO 7231 VISTAR 0151 VITYAZ 0071,1521	VIVAX 1651,2121,2601,3441 4111,4221,4281,4371,4381 4391,4451,8191 VIVID 1651 VIVO 8561,8571,8581 VIZIO 1761,3841 VORTEC 0021,1181,1361 VORTEX 4111,7451,7601 VOX 1871 VOXSON 0021,0071,1021,1181 1361,1761,2191 VU 2101,3951 WALKER 1871,8271 WALKIE 1511 WALTHAM 0221,0321,0751 0931,0951,1261,1361,1861 1871 WANSA 2601 WATSON 0021,0071,0081,1081 1181,1361,1701,1871,8271 WATT RADIO 0071,0151,0221 0591,0671,0951,1201,1351 1851 WEGA 1021,1061,1181,1361 2191 WEGAVOX 0021,0081,0591 0991,1181,1361,1701 WELLINGTON 1871,7481 WELLTECH 0041 WELTBlick 0021,1181,1361 1861 WESTINGHOUSE 3381 WESTINGHOUSE (ROKU TV) 3381 WESTON 1181,1361 WHARFEDALE 0021,1021,1181 1361 BEST 4784 BLAZER 0884 BOSHMAN 0884 BOTECH 0544,4784 BRITISH TELECOM 0194 BT 0021,0081 BT VISION 0194,0214,1494 3074,5134 BUSH 0704,1774,1964,2264 4664 CABLE ONE 1294,1314,2124 2404 CABLEMAS 2574 CABLETIME 1244,1254 CABOVISAO 0544 CANBRIDGE 0014,0194 CANAL + 'MEDIASAT' 0264 CANAL + 'SYSTEM+' 1174 CANAL DIGITAL 0264 CANAL SAT PILOTEME 0824 CANAL+ 0264,0814,0824,1144 1174,1584,2494 CANAL+ CANALSAT 1064,1174 1184,1454,1584 CGV 2504 CGV FREEVIEW 0834,0904 0974 CHARTER COMMUNICATIONS 2704 CISCO 2574 CITIZEN 4784 CLARIONS 0884 CLARKE-TECH 2394 CLEAR VIEW 0544 CLYDE CABLEVISION 1234 COBRA 0884 COMAG 0854,1014,2234 CREA 4784 D - SMART 0544 DAEWOO 1774 D-BOX 0104,1484 DGTEC 0884 DIGICAG 0544 DIGIFOX 1614 DIGIFREE 1774 DIGIFUSION 1774,4734 DIGIHOME 4784 DIGILINE 0544 DIGIMASTER 4784 DIGIQUEST 0544,0884,1574 1744,1824 DIGITAL 0884,4784 DIGITALBOX 0884,1614 DIGITRONIC 4784 DIGITSTAR 0884 DIGIWAVE 0884 DIGIX 0544 DIGIZAP 1774 DILOG 1644,3024,3034,3044 DISH TV 3614,4034 DISTRATEL 0534 DMT 0884,2874 DONGWON 0884 DR.HD 2394	ABCOM 0544 ADB 2474 AIRTEL 4024 AKAI 0194,1774,1964,4664 ALBA 4714,4724 ALBIS 2984 ALCAD 0884 ALITICE 1294 AMIKO 4344,4354 AMINO 4584 AMLOGIC 4134 AMPER 2904 AMSTRAD 0204,0374 ANKARO 4784 APEX 2134 ARCON 4784 ARIASAT 0544,0884,1654 1684,1704 ARION 2864,4784 ARRIS 3974,4844 ASTON 2334 ASTRA 1384 ASTRATEC 1774 AT&T 3224 ATOM 0884 ATASAT 0544 AUSTAR 0434,1444 AUXSTAR 4784 AVION 4784 AXIL 1344,1854 AXIS 1774 AZ-AMERICA 0884 AZBOX 3014 BALMET 1654 BAZEPORT 4064 BEIN 1364 BEST 4784 BLAZER 0884 BOSHMAN 0884 BOTECH 0544,4784 BRITISH TELECOM 0194 BT 0021,0081 BT VISION 0194,0214,1494 3074,5134 BUSH 0704,1774,1964,2264 4664,4714 CABLE ONE 1294,1314,2124 2404 CABLEMAS 2574 CABLETIME 1244,1254 CABOVISAO 0544 CANBRIDGE 0014,0194 CANAL + 'MEDIASAT' 0264 CANAL + 'SYSTEM+' 1174 CANAL DIGITAL 0264 CANAL SAT PILOTEME 0824 CANAL+ 0264,0814,0824,1144 1174,1584,2494 CANAL+ CANALSAT 1064,1174 1184,1454,1584 CGV 2504 CGV FREEVIEW 0834,0904 0974 CHARTER COMMUNICATIONS 2704 CISCO 2574 CITIZEN 4784 CLARIONS 0884 CLARKE-TECH 2394 CLEAR VIEW 0544 CLYDE CABLEVISION 1234 COBRA 0884 COMAG 0854,1014,2234 CREA 4784 D - SMART 0544 DAEWOO 1774 D-BOX 0104,1484 DGTEC 0884 DIGICAG 0544 DIGIFOX 1614 DIGIFREE 1774 DIGIFUSION 1774,4734 DIGIHOME 4784 DIGILINE 0544 DIGIMASTER 4784 DIGIQUEST 0544,0884,1574 1744,1824 DIGITAL 0884,4784 DIGITALBOX 0884,1614 DIGITRONIC 4784 DIGITSTAR 0884 DIGIWAVE 0884 DIGIX 0544 DIGIZAP 1774 DILOG 1644,3024,3034,3044 DISH TV 3614,4034 DISTRATEL 0534 DMT 0884,2874 DONGWON 0884 DR.HD 2394	DREAMBOX 2384,4784 DREAMVISION 4784 DSE 0894 DSN 0544 DSR 4784 DTM 4784 DUNE 1394,2974 ECHOSTAR 0544 ECHOSTAR 0074,2804,2814 2824,2834,2894 EDISION 0884,1634 ELECTRON 4784 ELLIES 0884,1544,1764 ENERGY SISTEM 0884 ENGEL 1344,1714,1744,1854 ENTONE 4474 E-SPACE 4784 EURODEC 0154,0164,0174 EUROSAT 1604,1744 EUROVOX 1464 EVOLUTION 1004,2954,2994 EYCOS 4784 FENNER 1774 FERGUSON 0004,1774,4604 4784 FILMNET 1214 FINEST 0544 FORCE 0554,1664 FOXTEL 0314,0324,0444,0474 0964,1304 FPE 2484 FREEBOX 1014,1084,1124 1824 FREESAT 3074 FREEVIEW 0944,4654,4664 4674,4684,4694,4704,4714 4724,4734,4744,4754,4764 FUBA 0544 G.I 4784 GALAXIS 1774 GESER 0884 GLOBALTEQ 4124 GOLDMASTER 0544,4784 GOLDSAT 1404 GOLDTOP 1774 GOODMANS 1774,2264,4294 4664,4714 GOSAT 3284,5084 GRUNDIG 0404,1514,2264 4694 HAUPPAUGE 4684 HE@D 1684,4784 HEMCO 0544 HIKVISION 4634 HIRSCHMANN 0284,0294,0854 1014,1524,1774 HITACHI 4714 HOMEZUS 2704,3104 HOMECASAT 1594 HORIZON 4404 HORNET 0544 HOTCHIP 0544 HOUSTON 0534 HUawei 3164,4274 HUMAX 0924,1614,1674,1744 1754,1774,2114,3074,4304 4754,5134 HYD 0544 HYUNDAI 0884,1804 ICECRYPT 1384,1414,5064 ICONQ 4614 ID SAT 0884 ILLUSION SAT 0884 INFOMIR 3184 INPAX 0884 INSIGHT 2464 INSIGNIA 3294 INTERSTAR 0544,1744 INVES 1774 IOTRONIC 0884 IPREMIUM 4134 IPTV ALCATEL LUCENT 2474 IPTV CISCO 2544 IRCO 0884 IVIEW 4364,4374,4384 JERROLD 1224 JVC 0194,4714 KABEL DIGITAL 1364 KAON 0544 KARTINA TV 1394 KIATEL 1774 KIATEL 0544 KÖNIG 0884,4784 KORAX 4784 KPN 1384,2004,4014 K-VISION 0884 KYOSTAR 0054,0884 LABGEAR 4704 LAVA 0884 LECHPOL 4784	LEDCOMX 0884 LECON 0234,0984,0994,1024 1034,1054 LEON 0884 LIDCOM 4664 LIFESAT 0234 LIDOS 1774 LOGIK 1774 LOGIX 0544 M7 4854 MACTEP 4784 MAG 2964 MAGIC 47				